

# PISTON/ROD RESET TOOL & PISTON HOLDER

For use on Cox .020, .049/.051 and .09 engines

## INSTRUCTIONS

1. Remove piston/rod assembly from engine.
2. Position piston/rod assembly over end of reset tool. Connecting rod will lay in slot.
3. Place piston holder on hard flat surface.
4. Insert piston/rod assembly and reset tool into piston holder and tap top of tool with a small hammer. Rotate tool between taps to assure top portion of socket is closed evenly. Continue tapping until almost all end-play between ball and socket is eliminated.
5. Proper end-play is .001 to .003 inches.
6. Striking force with hammer must be light for .020's, heavier for .049/.051's and .09's.

The need for resetting the ball/socket area will decrease as piston/cylinder fit loosens up.

**COX HOBBIES INC.**  
1525 E. WARNER AVE.  
SANTA ANA, CA 92705

